

Components listed below are quoted at incoming inspection.

**# 4 & 5 BEARING SCAVENAGE TUBE**

2-303-584-01

2-303-584-03

**#5 STRUT TUBE ASSEMBLY**

2-063-400-05

**4TH TURBINE NOZZLE HEAT SHEILD**

2-141-119-01

**ACTUATOR INTERSTAGE**

2-160-350-29

**ANTI ICING TUBE ASSEMBLY**

2-063-311-01

**BAFFLE - NO. 2 BEARING**

2-111-059-06

2-111-059-07

**BLEED BAND**

2-171-140-02

**BRACKET**

2-183-990-02

**BUS BAR**

2-303-353-02

2-303-353-04

**BUSHINGS**

2-131-129-01

**COMBUSTION HOUSING**

2-131-090-27

Components listed below are quoted at incoming inspection.

2-131-090-44  
2-131-090-47  
2-131-090-54  
2-131-090-59

**COMBUSTION LINER**

2-131-110-57  
2-131-110-59

**COWL SUPPORT**

2-043-360-03  
2-043-360-06

**CURL**

2-111-100-14  
2-111-100-17

**DEFLECTOR FIRESHIELD**

2-163-435-07  
2-163-435-08  
2-193-040-02  
2-193-040-03  
2-193-740-01

**DIFFUSER ASSEMBLY - AIR**

2-110-070-31  
2-110-070-34  
2-110-070-36  
2-110-070-40  
2-110-070-43  
2-110-070-44  
2-110-070R42  
2-110-070R45

**FAN SHROUD**

Components listed below are quoted at incoming inspection.

2-043-150-15

2-043-150-15A

**FORWARD OUTER LINER**

2-131-116-05

**FUEL CONTROL HOSE ASSEMBLY**

2-303-509-03

**FUEL CONTROL TO FLOW METER HOSE ASSEMBLY**

2-303-608-01

**FUEL MANIFOLD FIRESHIELD**

2-162-990-17

2-163-990-09

2-163-990-11

2-163-990-15

2-163-990-17

**FUEL TUBE**

2-303-315-02

**HEAT EXCHANGER TO FULL FLOW CHIP DETECTOR HOSE ASSEMBLY**

2-303-443-03

**HEAT EXCHANGER TO SHUTOFF VALVE HOSE ASSEMBLY**

2-303-319-01

**HOSE ASS'Y - STRUT TO OIL PUMP SCAVENGE**

2-303-325-02

**HOSE ASSEMBLY**

2-303-443-01

**HOUSING ASSEMBLY - NO. 2 BEARING**

2-101-640-21

2-101-640-23

Components listed below are quoted at incoming inspection.

2-101-640-26  
2-101-640R22  
2-101-640R24

**IN-LINE FUEL FILTER HOUSING ASSEMBLY**

2-303-176-01  
2-303-294-01  
2-303-294-02

**LINE ASSEMBLY**

2-303-225-01  
2-303-321-01

**MAIN FUEL FILTER ASSEMBLY**

2-263-440-01

**NOZZLE SUPPORT**

2-121-500-03  
2-121-500-04  
2-121-500-08

**NUMBER 4 STRUT FRAME TUBE ASSEMBLY**

2-063-410-02

**OIL INLET TUBE AND MANIFOLD ASSEMBLY**

2-063-600-04

**OIL INLET TUBE ASSEMBLY**

2-063-330-01

**OIL TANK**

2-163-820-07

**PIN MOUNT**

2-163-654-02

**RETAINER ASSEMBLY - COMPRESSOR**

Components listed below are quoted at incoming inspection.

2-101-650-12  
2-101-650-22  
2-101-650-27  
2-101-650R18  
2-101-650R21  
2-101-650R25

**RING - FIRST TURBINE SEAL**

2-111-058-03

**SEAL - NO. 2 POSITION FACE**

2-300-547-03

**SHROUD ASSEMBLY**

2-193-040-01

**SWIRLERS**

2-131-162-04  
2-131-162-05

**TAIL PIPE**

2-013-000-06  
2-013-000-06-E  
2-013-000-06PR8  
2-013-000-06RP8  
2-013-000-07  
2-013-000-07C1724  
2-013-000-07RP8  
2-013-000-08  
2-013-000-08RP8  
2-013-000-12  
2-013-000-12RP8

**TEMP. BULB COVER**

2-063-210-04

Components listed below are quoted at incoming inspection.

**TUBE ASSEMBLY**

2-193-520-01

2-263-100-01

2-303-377-01

**TUBE ASSEMBLY NUMBER 7 STRUT**

2-063-510-02

**UPPER ANTI-ICING TUBE ASSEMBLY**

2-303-301-01

**VANE ASSEMBLY**

2-131-120-11

**VANE SEGMENT**

2-131-510-01

2-131-510-02