

Components listed below are quoted at incoming inspection.

ACTUATING ARM

120-29649-001

120-29649-003

120-38366-001

AIR CONDITIONER GRIT

120-43409-001

AIR INLET

23065-1341

AIR INLET HEADER ASSEMBLY

120-45185-001

AIR INTAKE

120-18823-001

AIR SCOOP

120-30079-501

APU BLEED AIR DUCT

120-44167-001

120-44169-001

120-44169-013

APU EXHAUST DUCT

120-31260-001

120-43699-001

APU EXHAUST DUCT ASSEMBLY

120-43610-001

120-43610-601

ARMREST COVER

120-42143-001

ARMREST SUPPORT

Components listed below are quoted at incoming inspection.

120-38698-001

120-44434-001

120-44434-002

BLEED AIR DUCT

120-24945-001

120-24949-001

120-28946-013

120-44168-011

120-44169-017

BLEED AIR DUCT - TITANIUM

120-50495-009

BLEED AIR TUBE

120-23421-003

120-39892-001

BLEED AIR TUBE ASSEMBLY

120-39150-001

BLEED DUCT

120-34270-001

BRACKET

20437

20438

BYPASS DUCT ASSEMBLY

120-00424-017

CAM

120-49633-001

CHANNEL GUIDE

120-28659-001

Components listed below are quoted at incoming inspection.

COOLING DUCT

120-31227-001
120-31227-005
120-41720-001

COPILOTS ARMREST

120-42144-002

COWL DOOR

120-25602-020

DRAIN VENT

120-10470-001

DUCT ASSEMBLY

2203708-2
2215066-1

DUCT ASSEMBLY COMPRESSOR

2203749-1

ENGINE AIR INLET DUCT

120-36900-003
120-36900-004
120-42770-001
120-42770-002

EXHAUST COLLAR ASSEMBLY

120-46565-001

EXHAUST DUCT

120-04100-004
120-33750-004
120-33750-401
120-33750-402
120-49398-001

Components listed below are quoted at incoming inspection.

120-49398-401
120-49398-501
120-49398-502
120-49398-601
120-49398-602
120-49399-401
120-49399-402

EXHAUST PIPE

120-04100-401
120-04100-402
120-33750-003
120-49398-002

FAN COVER

30081-1100
30081-1101

FLAP CHANNEL GUIDE

120-28656-001
120-28656-002
120-28657-003
120-28658-001
120-28659-002

FLAP TRACK

120-17908-002
120-18506-001
120-28657-004
120-28658-002
120-33041-001
120-33041-002
120-33041-003
120-33041-004
120-33042-001

Components listed below are quoted at incoming inspection.

120-33042-002
120-33043-001
120-33043-002
120-33043-501
120-33043-502
120-33044-001
120-33044-002
120-33045-002
120-33045-501
120-33045-502
120-33046-001
120-33046-002
120-33046-004
120-33047-001
120-33047-002
120-33047-003
120-33047-004
120-33048-001
120-33048-002
120-33048-004
120-33056-002
120-33506-001
120-33506-003
120-33506-004
120-33507-002
120-33507-003
120-33507-004
120-50498-001
120-50498-002
120-50499-002
120-50500-001
120-50500-002
120-50501-001
120-50501-002

Components listed below are quoted at incoming inspection.

FLEXIBLE HOSE ASSEMBLY

S145000008-0174

FLOW CONTROL VALVE

3D2376-06

FORWARD EXHAUST DUCT SECTION

120-26109-004

FUEL CAP

2650266

GPU DOOR ASSEMBLY

120-37973-001

120-37973-005

H.P. BLEED AIR TUBE

120-36815-001

120-39895-001

120-39896-001

120-39897-001

120-49424-001

120-49425-001

HOUSING ASSEMBLY

120-27484-008

ICE DRAWER

4601334C501

INNER ARMREST

AM03078-138

LEFT HAND DUCT ASSEMBLY

120-42896-039

MIXING CHAMBER

Components listed below are quoted at incoming inspection.

120-37710-501

120-37710-503

120-37720-501

120-37720-503

MIXING DUCT ASSEMBLY

120-42864-001

120-42864-002

120-42864-014

120-42864-019

MOUNT ASSEMBLY

LM-430-2

MUFFLER CONDIT

120-37710-501

OXYGEN CYLINDER SUPPORT ASSEMBLY

120-35044-005

PILOT ARMREST ASSEMBLY

1B6010-21

PILOTS ARMREST

120-42144-001

PROP WRENCH

120/61-22

227-61-00

SAT1188-2

RIVETED ARM ASSEMBLY

123899-010

SEAT ARMREST STRUCTURE ASSEMBLY

120-42055-001

Components listed below are quoted at incoming inspection.

SOCKET WRENCH

EMB-001111-001

STRUCTURE ASSEMBLY

120-14285-001

THERMAL INSULATION BLANKET

120-27267-003

120-27267-005

120-27267-007

120-27267-009

120-27267-011

120-27267-015

120-27267-065

120-27267-087

120-28894-001

120-28894-002

120-28894-004

120-28895-001

120-28895-061

120-28896-001

120-28896-002

120-35410-001

120-35410-003

120-35410-005

120-35410-007

120-35410-009

120-35410-010

120-35410-011

120-35410-013

120-35410-015

120-35410-079

120-35410-087

120-35410-205

Components listed below are quoted at incoming inspection.

120-35411-001
120-35411-002
120-35411-025
120-35411-034
120-35411-035
120-35411-036
120-35413-001
120-35413-002
120-35413-036
120-35414-001
120-35424-001
120-35441-025
120-37410-011
120-50264-003
120-50264-005
120-50264-007
120-50264-009
120-50264-011
120-54310-003
401069-105
401069-109
401069-113
790106-1
790106-10
790106-2
790106-20

TORQUE WRENCH

005-631126

TUBE ASSEMBLY

120-08773-013
120-08773-015
120-10490-097
120-11291-001

Components listed below are quoted at incoming inspection.

120-11653-001
120-23421-501
120-24939-001
120-24942-001
120-24949-011
120-24952-013
120-24954-021
120-25627-001
120-25628-001
120-25629-001
120-26470-001
120-28947-013
120-33435-005
120-43700-501
120-44168-001
120-44168-019
120-50480-001
120-50481-001
120-50488-001
120-50488-011
120-50489-001
120-50489-011
120-50490-001
120-50491-001
120-50491-007
120-50495-001
120-63692-001

TUBE ASSEMBLY

120-31106-001

Tube Assembly

120-60841-003

VENT TUBE

Components listed below are quoted at incoming inspection.

120-33435-021

120-34290-001

120-34290-003

120-34290-005

120-34290-021

120-34290-025

120-34920-005

120-34920-021

VENTURI TUBE ASSEMBLY

120-24943-001

WATER EXTRACTOR

194542-2

WRENCH

227/61-00