

Components listed below are quoted at incoming inspection.

ANTI-ROTATION RING

3101072-01

COMBUSTION LINER INNER

3106163-01

3112377-01

COMBUSTION LINER OUTER

01R3105431-01

3037288

3040075

3040078

3040442

3040443

3052959-01

3103431-01

3103758-01

3105430-01

3105431-01

3110774-01

3112378-01

3112379-01

3112393-01

COOLING AIR NOZZLE

3111504-01 (SB20341)

H. P. DUCT

F10A5P20243-1

F10A5P20243-2

HP-IMPELLER SEAL HOUSING

3112442-01

INNER COMBUSTION LINER

Components listed below are quoted at incoming inspection.

3048934-01

INNER FRONT VANE RING HOUSING ASSEMBLY

3119965-01

3119966-01

INTERSTAGE TURBINE CASE

3106420-01

L. P. TURBINE HOUSING ASSEMBLY

3051008-01

L.P. TURBINE HOUSING ASSEMBLY

3108451-01

LARGE EXIT DUCT

3018995

LOW PRESSURE TURBINE SEAL HOUSING

3115638-01

LOW PRESSURE TURBINE STATOR ASSEMBLY

3042062

LP DIFFUSER EXIT DUCT

3110879-01

OIL TUBE ASSEMBLY

3119812-01

RING ADAPTOR

87800016-105

SMALL EXIT DUCT

3040610

3040612

3040613

3105383-02

Components listed below are quoted at incoming inspection.

3105385-01

3111549-01

3111551-01

3111554-01

3113687-01

Small Exit Duct

3044866-01

TURBINE EXHAUST DUCT

3110846-01

TURBINE EXIT DUCT

3108851-01

VANE RING FRONT INNER SUPPORT HOUSING

3112439-01

3114851-01

VANE RING OUTER SUPPORT HOUSING

3114448-01

VANE SUPPORT HOUSING

3111397-01